FIRE/SMOKE BARRIER FUNDAMENTALS FOR HEALTH CARE FACILITIES

William E. Koffel, P.E., FSFPE President Koffel Associates, Inc. <u>www.koffel.com</u> <u>wkoffel@koffel.com</u>



Expertly Engineering Safety From Fire

OBJECTIVE

- Identify the different types of barriers used in health care facilities
- Identify the key characteristics for each barrier
 - Continuity
 - Protection of openings
- List at least three strategies that can be used to improve a barrier management program



TYPES OF WALL ASSEMBLIES

- Exterior walls
- Fire walls
- Fire barriers
- Fire partitions No such assembly in NFPA
- Smoke barriers
- Smoke partitions



FIRE TESTED WALL ASSEMBLIES


- In accordance with ASTM E119/UL263
- Resist passage of heat and hot gases
- Structural integrity during the test fire
- Have something left at the end of the test



FIVE POINTS

- Required fire-resistance rating
- Continuity
- Openings and penetrations
- Types of materials
- Structural robustness








FIRE BARRIERS

- Fire barriers are used in the following applications:
 - Fire area separations
 - Mixed occupancy separations
 - Incidental use areas
 - Hazardous area separations
 - Exit enclosures
 - Shaft enclosures
 - Horizontal exits
 - Corridor walls NFPA only







SUPPORT

- Supported by construction with the same fireresistance rating as the fire barrier
- Some exceptions
 - Vary between NFPA and ICC



SUMMARY OF FIRE BARRIERS

| Issue | Requirement |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Required Fire-Resistance Rating | Depends upon specific use |
| Required continuity | Floor/ceiling below to deck above |
| Openings | General: Aggregate glazing area (or width) <25% wall area/length; maximum size 120 sf. Specific: Rules based on use of barrier |
| Types of materials | As required for the type of construction |
| Robustness of structural system | If load bearing, fire tested with load |



 \bigcirc

FIRE PARTITIONS

- Fire partitions are used in the following applications:
 - Dwelling units separations
 - Sleeping units in Group R-1, R-2 and I-1
 - Tenant separation in covered malls
 - Exit access corridor walls
 - Elevator lobby separation
- Remember, NFPA does not use this phrase



SUMMARY OF FIRE PARTITIONS

| Issue | Requirement |
|---------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Required Fire-Resistance Rating | 1 hour, with exceptions, depending on use. For corridors see Table in Chapter $10 - IBC$ only |
| Required continuity | Floor/ceiling below to deck above or tight to underside of fire-resistance rated assembly. Supported by fire- resistance rated construction, except in corridors, tenant, and guestroom separations in Types IIIB and VB construction |
| Openings | 20 minutes (w/o hose stream) for corridors 45 minutes for all others |
| Types of materials | As required for the type of construction |
| Robustness of structural system | If load bearing, fire tested with load |



SMOKE BARRIERS

- Smoke barriers are used in the following applications:
 - Group I-2
 - Group I-3
 - Areas or refuge
 - Other specific applications



SUMMARY OF SMOKE BARRIERS

| Issue | Requirement |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Required Fire-Resistance Rating | 1-hour with the exception that a construction of a minimum 0.1" thick steel in Group I-3 buildings is allowed |
| Required continuity | Horizontal: Outside wall to outside wall Vertical: Floor to slab or deck above, continuous through interstitial spaces Supporting construction may be required based upon the applicable codes |
| Openings | 20 minutes – but not a true fire door in NFPA 101 Smoke- and draft-controlled doors tested in accordance with UL 1784 – IBC only |
| Types of materials | As required for the type of construction |
| Robustness of structural system | If load bearing, fire tested with load |



SMOKE PARTITIONS


- Smoke partitions are used in the following applications:
 - Corridor walls in Group I-2 IBC only
 - Sprinkler protected hazardous areas NFPA



SUMMARY OF SMOKE PARTITIONS

| Issue | Requirements |
|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Required Fire-Resistance Rating | Not required (unless otherwise required) |
| Required continuity | Floor/ceiling below to deck above or tight to underside of ceiling membrane in ceiling membrane designed to limit passage of smoke Difference between NFPA/ICC for ceiling tiles |
| Openings | Windows: Sealed to resist free passage of smoke Doors: No louvers Air leakage rated (UL 1784) – IBC??? Self closing, or automatic closing by smoke detectors |
| Types of materials | As required for the type of construction |
| Robustness of structural system | If load bearing, fire tested with load |
| | |

LS DRAWING INFORMATION





LS DRAWING INFORMATION

- A legend that clearly identifies features of fire safety
- Areas of the building that are fully sprinklered (if the building is partially sprinklered)
- Locations of all hazardous storage areas
- Locations of all rated barriers
- Locations of all smoke barriers
- Suite boundaries, including the size of the identified suites both sleeping (max 5,000 sq ft) and non-sleeping (max 10,000 sq ft) – CMS Memorandum dated August 30, 2013
- Locations of designated smoke compartments
- Locations of chutes and shafts
- Any approved equivalencies or waivers



SUCCESSFUL STRATEGIES

BUILD IT CORRECTLY

- Thorough plan review process
- Contractor qualifications
- Commissioning systems and buildings

 NFPA 3, NFPA 4, ASHE documents, pending ICC std.
- Complete SOC documentation while contractor still on site
- Use of certified inspectors or special inspectors





BUILD IT CORRECTLY!!





SUCCESSFUL STRATEGIES

- Make sure all rehabilitation work is done correctly
 - Refer to previous slides
- Above ceiling work permits
 - Means to identify "approved" individuals
- Proper identification
 - Labels
 - Marking
 - Life Safety Drawings







ADDITIONAL RESOURCES

 Visit <u>www.koffel.com</u> for links to a LinkedIn Life Safety Code Discussion Group

- NFPA
 - www.NFPA.org/###

• ASHE





QUESTIONS AND DISCUSSION



Expertly Engineering Safety From Fire